

STOP!

**Do not install until you have read these instructions
Call 800.465.6909 with any questions**

HANDLING AND INSTALLATION INSTRUCTIONS

Ajiro™, Inlay Earth Fibers™, and Marquetry Grass Wallcoverings
(MR-AC, AD1, AM1, AM3, series) (MR-EB, EM1, EM3 series)

This is not a seamless product.

General Guidelines

- AD1: 9" x 10" REPEAT, AM1/AM3: 17" REPEAT
- Inspect goods carefully. Grade carefully for color flow. Confirm that you have the correct color and product before installing. Color variation is normal.
- No returns on cut goods.
- No claims allowed under any conditions for labor charges or consequential damages.
- Wallcoverings can display certain irregularities that are inherent to the manufacturing process.
- Confirm that you have the correct color and product before installing.
- **No allowances will be made after two drops.**
Stop and call 800.465.6909 immediately if you encounter any difficulties

Actions to Avoid

DO NOT:

- Place hot iron directly on wallcovering.
- Do not let paste dry on the face of the product.
- Do not rub face of the product with a stiff brush.
- Do not pull panels once they have been placed on the wall: this will cause the seams to open after the product dries.
- Do not use a seam roller to set the seams. Instead, use a plastic sweep.
- Avoid soaking the paper in water or getting the wallcovering excessively wet. This can cause shrinkage and opening of seams as the wallcovering dries.
- Avoid direct or bright reflected sunlight. Not guaranteed against fading or color change.
- Do not crease wallcovering.



STOP!

**Do not install until you have read these instructions
Call 800.465.6909 with any questions**

HANDLING AND INSTALLATION INSTRUCTIONS

Ajiro™, Inlay Earth Fibers™, and Marquetry Grass Wallcoverings

(MR-AC, AD1, AM1, AM3, series) (MR-EB, EM1, EM3 series)

This is not a seamless product.

Installation Instructions

PRIMER

- Walls should be painted with a good quality flat Latex wallpaint, and be mirror-smooth. Paint should be tinted to match the color of the wallcovering.

ADHESIVE

- Use a good quality CLEAR, STRIPPABLE, PRE-MIXED VINYL ADHESIVE.
- Apply evenly and adequately. Along the edges, apply paste thicker to avoid seams opening.
- Avoid soaking the paper in water or getting the wallcovering excessively wet. This can cause shrinkage and opening of seams as the wallcovering dries.
- DO NOT fold after pasting, creases may be difficult to smooth out.
- Pre-paste seam line and all edges prior to installing.

TRIMMING

- Trim edges with a very sharp razor blade if needed.
- Side matching is approximate. Be sure that grain on both sides of each seam line runs in same direction.
- **It is not uncommon for squares to lift from the paper backing during/prior to installation. This can be repaired by applying heat to the area. Place a piece of clean white paper on the face of the area and apply an iron (on warm) with pressure to re-set the square.**

RELAXING TIME

- It is essential to allow wallcoverings sufficient relaxing time to avoid Bubbling, Shrinking and Seam Opening. Allow the paste enough time to soak into a sheet before hanging.
- Usual Relaxing Time: 5 to 8 minutes
- Do a small test strip to determine the proper relaxing time.
- WIPE OFF EXCESS PASTE IMMEDIATELY WITH A SOFT DAMP CLOTH. DON'T SCRUB. DON'T RUB.

TOOLS

- Adhere product to the wall using a Soft Bristled Nylon Brush.
- Gently smooth product to the wall using a Plastic Smoother. Smooth continuously to remove any bubbles.

1/08/07
PAGE 2

CONTINUED →



MAYA ROMANOFF®

p 773.465.6909 f 773.465.7089 www.mayaromanoff.com

STOP!

Do not install until you have read these instructions
Call 800.465.6909 with any questions

Ajiro™, Inlay Earth Fibers™, and Marquetry Grass Wallcoverings
(MR-AC, AD1, AM1, AM3, series) (MR-EB, EM1, EM3 series)

This is not a seamless product.

Supplemental Installation Instructions: Wrapping Outside Corners

1. Be sure the corners are smooth and square before beginning installation.
2. **Pre-size the area to be installed with CLEAR, STRIPPABLE, PRE-MIXED VINYL ADHESIVE prior to installation and let it dry.**
3. Avoid setting the corners in the product on the outside corner. Place the product so the outside corner will fall in the middle of the long side of the squares or diamonds. (For this reason the installation should begin with the outside corner if possible.)
4. **The installer should pre-paste ONLY the area that is to be wrapped. The section to be wrapped should have as large a portion of the diamond, square, or chevron as possible on each side of the corner (See #3 above).**
5. Check the flexibility of the corner after the product has relaxed for the appropriate booking time.
6. If the corner bends easily, paste the entire drop and let it book for the appropriate relaxing time.
7. Check the flexibility of the corner area—if there is resistance allow additional relaxing time.
8. Apply the product to the wall.
9. If there is resistance while turning the corner, a second pasting and additional booking may be required.
10. It is extremely important that the corner not be forced. If the product is not ready to bend, it may split.
11. **If you have any questions, STOP and contact Maya Romanoff Corporation at 800.465.6909.**

- If you want to put an additional protective coating on this product, such as an undiluted acrylic polyurethane, always do a test on scrap material before applying to the wall. Maya Romanoff is not responsible for unsatisfactory results.
- For a 20% up charge on your order, we can apply an additional protective coating.

