

STOP!

**Do not install until you have read these instructions
Call 800.465.6909 with any questions**

HANDLING AND INSTALLATION INSTRUCTIONS

Custom Beadazzled™ Flexible Glass Bead Wallcovering Murals
(MR-BD-Mural series)

Handle this product like a silk wallcovering.

This is not a seamless product. Lighting will affect appearance of final installation.

Special Handling Required

- Store the material between 60-85° F in a dry place.
- Store box upright: Do Not Stack.
- Prolonged storage is not recommended. Check label on box for install by date.
- This product cannot be double cut on the wall; trim the material from the back side on a table.

General Guidelines

- Inspect goods carefully. No returns on cut goods.
- Confirm that you have the correct color and product before installing.
- **No allowances will be made on custom murals.**
Call 800.465.6909 immediately if you encounter any difficulties.
- No claims allowed for labor charges or consequential damages under any conditions.
- Wallcoverings can display certain irregularities that are inherent to the manufacturing process.
- Do not reverse roll product.
- Do not reverse hang.

Actions to Avoid

- Do not trim from the front whenever possible.
- Do not get paste on the face of the product.
- Do not crease wallcovering.
- Do not pull panels once they have been placed on the wall: this will cause the seams to open after the product dries (Treat the product like a silk wallcovering).
- Avoid direct or bright sunlight. Not guaranteed against fading or color change.



STOP!

Do not install until you have read these instructions Call 800.465.6909 with any questions

Custom Beadazzled™ Flexible Glass Bead Wallcovering Murals (MR-BD-Mural series)

Handle this product like a silk wallcovering.

This is not a seamless product. Lighting will affect appearance of final installation.

WALL PREPARATION

- Paint the wall the color of the product with a good quality, non-sealing flat latex wallpaint.
- Apply a coat of the HEAVY DUTY, CLEAR PRE-MIXED, VINYL, LOW WATER CONTENT adhesive* to the wall.
- Walls must be completely dry before installation can begin.

ADHESIVE

- Use a HEAVY DUTY, CLEAR, PRE-MIXED, VINYL, LOW WATER CONTENT adhesive*. Apply a generous, even coat of adhesive to the product being careful at the edges so that adhesive does not get on any overhanging beads. Allow to rest 5-8 minutes.
- To avoid getting paste on face of product, use a 3/8" nap roller to apply adhesive.
- You can protect the face of the installed drops from adhesive using 3M Blue Tape.

• If you encounter any difficulties, DO NOT CONTINUE. Call 800.465.6909 immediately.

TRIMMING

- Trim with a very sharp, single edge razor blade. USE A NEW BLADE FOR EACH CUT.
- Exposed edges should be installed using the factory edge. Create a template for tight corners or any surface that is not square. When you cannot make a template, warming with a hair dryer will allow easier trimming (from face only).
- Color edges of panel to match image used.
- If trimming is needed, ideally trim the material from the back side on a table. This product cannot be double cut on the wall.

TOOLS

- Adhere product to the wall using a bristled nylon brush.
- Smooth product to the wall using a plastic smoother. Smooth continuously to remove any bubbles.
- Use a wooden seam roller to set the seams.
- Use a "corner roller" to ease the material into moldings, casework, etc., prior to trimming.
- Once product is adhered to wall, warming with a hair dryer on seams will allow you to push seams tightly together. USE CARE!

CEILINGS

- Ceiling installations require a two man team.
- For ceiling installation, prep ceiling with 'VINYL ON VINYL' adhesive. ALLOW TO TACK UP.
- Apply 'VINYL ON VINYL' adhesive to the product. Use a 3/8" nap roller to apply adhesive to avoid getting any paste on seam lines. (Getting paste on seams may cause yellowing.) Allow to rest **5-8 minutes**.
- **DO NOT GET PASTE ON FACE OR EDGES OF PRODUCT, SIMILAR TO A SILK TEXTILE INSTALLATION.**

CLEANING

- Blot any excess debris—do not rub.
- Dampen the area using a soft cloth and a very weak solution of a very mild liquid detergent.
- Use 'canned air' to raise any imbedded material to the surface.
- Blot the product dry with a soft cloth.

* We recommend Dynamite 234 by Gardner Gibson Products, www.gardner-gibson.com