

STOP!

**Do not install until you have read these instructions
Call 800.465.6909 with any questions**

HANDLING AND INSTALLATION INSTRUCTIONS

Beadazzled Lite™ Flexible Glass Bead Wallcovering
(MR-BL series)

This is not a seamless product. Lighting will affect appearance of final installation.

General Guidelines

- Inspect goods carefully. No returns on cut goods.
- Confirm that you have the correct color and product before installing.
- **No allowances will be made after two drops.**
Call 800.465.6909 immediately if you encounter any difficulties.
- No claims allowed for labor charges or consequential damages under any conditions.
- Wallcoverings can display certain irregularities that are inherent to the manufacturing process.
- The product CAN be double-cut on the wall using 3M blue tape to protect face of wallcovering from paste.

Actions to Avoid

- Do not get paste on the face of the product.
- Do not crease wallcovering.
- Do not pull panels once they have been placed on the wall: this will cause the seams to open after the product dries
- Avoid direct or bright sunlight. Not guaranteed against fading or color change.

10/31/06
PAGE 1

CONTINUED →



MAYA ROMANOFF®

1730 West Greenleaf, Chicago, IL 60626 p 773.465.6909 f 773.465.7089 www.mayaromanoff.com

STOP!

**Do not install until you have read these instructions
Call 800.465.6909 with any questions**

Beadazzled Lite™ Flexible Glass Bead Wallcovering (MR-BL series)

This is not a seamless product. Lighting will affect appearance of final installation.

WALL PREPARATION

- Paint the wall the color of the product with a good quality flat latex wallpaint.
- Apply a coat of the HEAVY DUTY, CLEAR PRE-MIXED, VINYL, LOW WATER CONTENT adhesive to the wall.
- Walls must be completely dry before installation can begin.

ADHESIVE

- Use a HEAVY DUTY, CLEAR, PRE-MIXED, VINYL, LOW WATER CONTENT adhesive (Dynamite 234). Apply a generous, even coat of adhesive to the product being careful at the edges so that adhesive does not get on any overhanging beads. Allow to rest 5-8 minutes.
- To avoid getting paste on face of product, use a 3/8" nap roller to apply adhesive.
- You can protect the face of the installed drops from adhesive using 3M Blue Tape.

• Stop after installing two panels if you encounter any difficulties.

Call 800.465.6909 immediately.

TRIMMING

- Trim with a very sharp, single edge razor blade. USE A NEW BLADE FOR EACH CUT.
- **Product can be double-cut on the wall.** Create a template for tight corners or any surface that is not square.

TOOLS

- Adhere product to the wall using a bristled nylon brush.
- Smooth product to the wall using a plastic smoother. Smooth continuously to remove any bubbles.
- Use a wooden seam roller to set the seams.
- Use a "corner roller" to ease the material into moldings, casework, etc., prior to trimming.

CLEANING

- Blot any excess debris—do not rub.
- Dampen the area using a soft cloth and a very weak solution of a very mild liquid detergent.
- Use 'canned air' to raise any imbedded material to the surface.
- Blot the product dry with a soft cloth.

10/31/06
PAGE 2

CONTINUED →



MAYA ROMANOFF®

1730 West Greenleaf, Chicago, IL 60626 p 773.465.6909 f 773.465.7089 www.mayaromanoff.com