

STOP!

**Do not install until you have read these instructions
Call 800.465.6909 with any questions**

HANDLING AND INSTALLATION INSTRUCTIONS

David Rockwell for Maya Romanoff Blanket™ Wallcoverings
(MR-BK series)

General Guidelines

- BK-01: 7" REPEAT, BK-03: 7" REPEAT, BK-06: 54" REPEAT
- Inspect goods carefully. Grade carefully for color flow. Confirm that you have the correct color and product before installing. Color variation is normal. This is a hand-made product.
- No returns on cut goods.
- No claims allowed under any conditions for labor charges or consequential damages.
- Wallcoverings can display certain irregularities that are inherent to the manufacturing process.
- Confirm that you have the correct color and product before installing.
- **No allowances will be made after two drops.**

Stop and call 800.465.6909 immediately if you encounter any difficulties.

Actions to Avoid

DO NOT:

- Place hot iron directly on wallcovering.
- Do not let paste dry on the face of the product.
- Do not rub face of the product with a stiff brush.
- Do not pull panels once they have been placed on the wall: this will cause the seams to open after the product dries.
- Avoid direct or bright reflected sunlight. Not guaranteed against fading or color change.



STOP!

**Do not install until you have read these instructions
Call 800.465.6909 with any questions**

HANDLING AND INSTALLATION INSTRUCTIONS

David Rockwell for Maya Romanoff Blanket™ Wallcoverings
(MR-BK series)

Installation Instructions

PRIMER

- Walls should be painted with a good quality flat Latex wallpaint, and be mirror-smooth. Paint should be tinted to match the color of the wallcovering.

ADHESIVE

- **Paste wall directly. Do not paste the wallcovering!**
- Use a good quality CLEAR, STRIPPABLE, LOW MOISTURE, PRE-MIXED VINYL ADHESIVE (Pro-880)
- Apply evenly and adequately. Apply paste thicker where seams will fall.
- Avoid getting paste on face of the wallcovering.

TRIMMING

- Double-cut edges (DRY) on the wall with a very sharp razor blade. Use one blade per cut.

TOOLS

- Gently smooth product to the wall using a Plastic Smoother. Smooth continuously to remove any bubbles.
- Do not smooth face of product with a bristle brush or any other textured smoothing implement.

03/23/08
PAGE 2



M A Y A R O M A N O F F®