

# STOP!

**Do not install until you have read these instructions  
Call 800.465.6909 with any questions**

## **HANDLING AND INSTALLATION INSTRUCTIONS**

David Rockwell for Maya Romanoff  
Blanket™ Wallcoverings (MR-BK series)

### **General Guidelines**

- BK-01: 7" REPEAT, BK-03: 7" REPEAT
- Inspect goods carefully. Grade carefully for color flow. Confirm that you have the correct color and product before installing.
- No returns on cut goods.
- No claims allowed under any conditions for labor charges or consequential damages.
- Wallcoverings can display certain irregularities that are inherent to the manufacturing process.
- **No allowances will be made after two drops.**

Stop and call 800.465.6909 immediately if you encounter any difficulties.

### **Actions to Avoid**

#### DO NOT:

- Do not double cut on the wall.
- Do not let paste dry on the face of the product.
- Do not rub face of the product with a stiff brush.
- Do not pull panels once they have been placed on the wall: this will cause the seams to open after the product dries.
- Avoid direct or bright reflected sunlight. Not guaranteed against fading or color change.



# STOP!

**Do not install until you have read these instructions  
Call 800.465.6909 with any questions**

## **HANDLING AND INSTALLATION INSTRUCTIONS**

David Rockwell for Maya Romanoff  
Blanket™ Wallcoverings (MR-BK series)

### Installation Instructions

#### PRIMER

- Walls should be painted with a good quality, non-sealing flat Latex wallpaint, and be mirror-smooth. Paint should be tinted to match the color of the wallcovering.

#### ADHESIVE

- **Paste wall directly. Do not paste the wallcovering!**
- Use a good quality CLEAR, STRIPPABLE, LOW MOISTURE, PRE-MIXED VINYL ADHESIVE\*.
- Apply evenly and adequately. Apply paste thicker where seams will fall.
- Avoid getting paste on face of the wallcovering.

#### TRIMMING

- Trim edges with a very sharp razor blade to true. Use a new blade for each cut.
- Do not double cut on the wall.

#### TOOLS

- Gently smooth product to the wall using a Plastic Smoother. Smooth continuously to remove any bubbles.
- Do not smooth face of product with a bristle brush or any other textured smoothing implement.

\* We recommend Professional® Pro 880 by Roman Decorating Products, 800-488-6117, [www.romandecoratingproducts.com](http://www.romandecoratingproducts.com)

03/11/09  
PAGE 2



MAYA ROMANOFF®

Chicago Headquarters: 3435 Madison, Skokie, IL 60076 † 1.773.465.6909 ‡ 1.773.465.7089 [www.mayaromanoff.com](http://www.mayaromanoff.com)