

# STOP!

**Do not install until you have read these instructions  
Call 800.465.6909 with any questions**

## **HANDLING AND INSTALLATION INSTRUCTIONS**

Abacadazzle™, Island Weaves™ and Earth Fibers™ Wallcovering  
(MR-DZ, MR-TK and MR-EF series)

**Product woven with natural grasses. Slubs/other irregularities will  
appear from time to time within some rolls.**

### General Guidelines

- Inspect goods carefully. Grade carefully for color flow. Confirm that you have the correct color and product before installing. Additional yardage from this dye-lot may not be available.
- No claims allowed for labor charges or consequential damages under any conditions.
- No allowances for more than three standard (9 ft) drops.
- Wallcoverings can display certain irregularities that are inherent to the manufacturing process.
- Walls should be mirror-smooth. Lining paper should be used if walls have imperfections.
- NO SIDE MATCH.

### Actions to Avoid

#### DO NOT:

- Do not rub face of the product with a stiff brush.
- Do not pull panels once they have been placed on the wall: this will cause the seams to open after the product dries.
- Do not use a seam roller to set the seams. Instead, use a plastic sweep.
- Avoid soaking the paper in water or getting the wallcovering excessively wet. This can cause shrinkage and opening of seams as the wallcovering dries.
- Avoid direct or bright reflected sunlight. Not guaranteed against fading or color change.
- Do not crease wallcovering.

3/15/06

CONTINUED →



# MAYA ROMANOFF

1730 West Greenleaf, Chicago, IL 60626 p 773.465.6909 f 773.465.7089 www.mayaromanoff.com

# STOP!

**Do not install until you have read these instructions  
Call 800.465.6909 with any questions**

## **HANDLING AND INSTALLATION INSTRUCTIONS**

Abacadazzle™, Island Weaves™ and Earth Fibers™ Wallcovering  
(MR-DZ, MR-TK and MR-EF series)

**Product woven with natural grasses. Slubs/other irregularities will  
appear from time to time within some rolls.**

### Installation Instructions

#### PRIMER

- Walls should be painted with a good quality flat Latex wallpaint. Paint should be tinted to match the color of the wallcovering. Walls must be completely dry before installation can begin.

#### ADHESIVE

- Use a good quality CLEAR, STRIPPABLE, PRE-MIXED VINYL ADHESIVE.
- Apply evenly and adequately. Along the edges, apply paste thicker to avoid seams opening.
- DO NOT fold after pasting, creases may be difficult to smooth out.

#### TRIMMING

- Trimming required only if necessary. (i.e.: rough edges)

#### RELAXING TIME

- It is essential to allow wallcoverings sufficient relaxing time to avoid Bubbling, Shrinking and Seam Opening. Allow the paste enough time to soak into a sheet before hanging.
- Usual Relaxing Time: 8 to 15 minutes
- Do a small test strip to determine the proper relaxing time.
- WIPE OFF EXCESS PASTE IMMEDIATELY WITH A SOFT DAMP CLOTH. DON'T SCRUB. DON'T RUB.

#### TOOLS

- Adhere product to the wall using a Soft Bristled Nylon Brush.
- Gently smooth product to the wall using a Plastic Smoother. Smooth continuously to remove any bubbles.

5/1/06

CONTINUED →



# MAYA ROMANOFF

1730 West Greenleaf, Chicago, IL 60626 p 773.465.6909 f 773.465.7089 www.mayaromanoff.com