

STOP!

**Do not install until you have read these instructions
Call 800.465.6909 with any questions**

HANDLING AND INSTALLATION INSTRUCTIONS

Jewel™ Wallcovering

(MR-YE, MR-YM, MR-YP, MR-YS, MR-YK, MR-YW, MR-YH, MR-YT)

General Guidelines

- Inspect goods carefully. Grade carefully for color flow. Confirm that you have the correct color and product before installing. Additional yardage from this dye-lot may not be available.
- No claims allowed for labor charges or consequential damages under any conditions.
- No allowances for more than three standard (9 ft) drops.
- Wallcoverings can display certain irregularities that are inherent to the manufacturing process.
- Walls should be mirror-smooth. Lining paper should be used if walls have imperfections.
- NO SIDE MATCH.
- Excess metallic gold/silver may appear on your rag/sponge after initial wiping. This is normal and will not take away from the beauty of the installation.

Actions to Avoid

DO NOT:

- Do not rub face of the product with a stiff brush.
- Do not pull panels once they have been placed on the wall: this will cause the seams to open after the product dries.
- Do not use a seam roller to set the seams. Instead, use a plastic sweep.
- Avoid soaking the paper in water or getting the wallcovering excessively wet. This can cause shrinkage and opening of seams as the wallcovering dries.
- Avoid direct or bright reflected sunlight. Not guaranteed against fading or color change.
- Do not crease wallcovering.



STOP!

**Do not install until you have read these instructions
Call 800.465.6909 with any questions**

HANDLING AND INSTALLATION INSTRUCTIONS

Jewel™ Wallcovering

(MR-YE, MR-YM, MR-YP, MR-YS, MR-YK, MR-YW, MR-YH, MR-YT)

Installation Instructions

PRIMER

- Walls should be painted with a good quality, non-sealing flat Latex wallpaint. Paint should be tinted to match the color of the wallcovering.

ADHESIVE

- Use a good quality CLEAR, STRIPPABLE, PRE-MIXED VINYL ADHESIVE. Apply evenly, making sure that edges receive adequate coverage.
- CLAY BASED ADHESIVES WILL STAIN.

TRIMMING

- Trim edges with a very sharp razor blade to true. Use a new blade for each cut.

RELAXING TIME

- It is essential to allow wallcoverings sufficient relaxing time to avoid Bubbling, Shrinking and Seam Opening. Allow the paste enough time to soak into a sheet before hanging.
- Usual Relaxing Time: 4 to 6 minutes
- Do a small test strip to determine the proper relaxing time.
- WIPE OFF EXCESS PASTE IMMEDIATELY WITH A SOFT DAMP CLOTH. DO NOT SCRUB, DO NOT RUB.

TOOLS

- Adhere product to the wall using a Soft Bristled Nylon Brush.
- Gently smooth product to the wall using a Plastic Smoother.

IMPORTANT INFORMATION

- MR-YP-28 is hand-stamped by copper plates. Plate overlap repeats approximately every 35".
- PEARL may be side matched in darker colors.
- All others do not have a repeat, no exact side-match.

