

# STOP!

**Do not install until you have read these instructions  
Call 800.465.6909 with any questions**

## **HANDLING AND INSTALLATION INSTRUCTIONS**

### Sentimentale™ Wallcovering (MR-GF series)

#### General Guidelines

- Inspect goods carefully. Grade carefully for color flow. Confirm that you have the correct color and product before installing. Additional yardage from this dye-lot may not be available.
- No claims allowed for labor charges or consequential damages under any conditions.
- No allowances for more than three standard (9 ft) drops.
- Wallcoverings can display certain irregularities that are inherent to the manufacturing process.
- Walls should be mirror-smooth. Lining paper should be used if walls have imperfections.
- **ARBORETUM:** approx. 25" repeat
- **FILIGREE:** approx. 12 1/2" repeat
- **HARLEQUIN:** straight across match.
- **MIRAGE/COLONNADE:** have no side match or repeat.

#### Actions to Avoid

##### DO NOT:

- Do not rub face of the product with a stiff brush.
- Do not pull panels once they have been placed on the wall: this will cause the seams to open after the product dries.
- Do not use a seam roller to set the seams. Instead, use a plastic sweep.
- Avoid soaking the paper in water or getting the wallcovering excessively wet. This can cause shrinkage and opening of seams as the wallcovering dries.
- Avoid direct or bright reflected sunlight. Not guaranteed against fading or color change.
- Do not crease wallcovering.

3/15/06

CONTINUED →



# MAYA ROMANOFF

1730 West Greenleaf, Chicago, IL 60626 p 773.465.6909 f 773.465.7089 www.mayaromanoff.com

# STOP!

**Do not install until you have read these instructions  
Call 800.465.6909 with any questions**

## **HANDLING AND INSTALLATION INSTRUCTIONS**

### Sentimentale™ Wallcovering (MR-GF series)

#### Installation Instructions

##### **PRIMER**

- Walls should be primed with a good quality Latex or Acrylic Latex Primer. Primer may be tinted to match the color of the wallcovering.

##### **ADHESIVE**

- Use a good quality CLEAR, STRIPPABLE, PRE-MIXED VINYL ADHESIVE (PRO 880). Apply evenly, making sure edges get adequate coverage. Low water content important to trouble-free installations. We advise that you not mix your own adhesive.

##### **TRIMMING**

- For your convenience this product has been pre-trimmed. If trimming is necessary, trim edges with a very sharp razor blade.

##### **RELAXING TIME**

- It is essential to allow wallcoverings sufficient relaxing time to avoid Bubbling, Shrinking and Seam Opening. Allow the paste enough time to soak into a sheet before hanging.
- Usual Relaxing Time: 4-5 minutes
- Do a small test strip to determine the proper relaxing time.
- WIPE OFF EXCESS PASTE IMMEDIATELY WITH A SOFT DAMP CLOTH. DON'T SCRUB. DON'T RUB.

##### **TOOLS**

- Adhere product to the wall using a good quality Stiff Smoothing Brush.
- Smooth product to the wall using a Plastic Smoother.

3/15/06

CONTINUED →



# MAYA ROMANOFF

1730 West Greenleaf, Chicago, IL 60626 p 773.465.6909 f 773.465.7089 www.mayaromanoff.com