

STOP!

**Do not install until you have read these instructions
Call 800.465.6909 with any questions**

HANDLING AND INSTALLATION INSTRUCTIONS

Custom Beadazzled™ Flexible Glass Bead Wallcovering Murals (MR-BD series)

This is not a seamless product. Lighting will affect appearance of final installation.

QUICK FACTS

- Paste: Maya Romanoff's MR-RA-838-1 or MR-RA-838-5 or a good quality heavy-duty, pre-mixed, non-strippable, clear, vinyl, low water content adhesive.
- All Beadazzled must be installed within 6-8 weeks from date of shipment.
- Table-trim from the back.
- Level 5 finish.
- Prepaste the wall.
- Relax 5-8 minutes.
- Handle this product like a silk wallcovering.
- Please read the following installation instructions before proceeding.
- **IF YOU DO NOT FOLLOW OUR INSTALLATION INSTRUCTIONS, MAYA ROMANOFF WILL NOT ACCEPT RESPONSIBILITY FOR THE INSTALLATION—YOU WILL BE INSTALLING AT YOUR OWN RISK.**

SPECIAL HANDLING REQUIRED

- Store the material between 60-85° F in a dry place.
- Store box upright: Do Not Stack.
- Prolonged storage is not recommended. Check label on box for install by date. Product must be kept in a temperature controlled environment.
- This product cannot be double-cut on the wall; trim the material from the back side on a table.

GENERAL GUIDELINES

- Inspect goods carefully. No returns on cut goods.
- Confirm that you have the correct color and product before installing. Additional yardage from this dye lot may not be available.
- **No allowances will be made on custom murals—Call 800.465.6909 immediately if you encounter any difficulties.**
- No claims allowed for labor charges or consequential damages under any conditions.
- Wallcoverings can display certain irregularities that are inherent to the manufacturing process.

ACTIONS TO AVOID

- Do not reverse roll product or reverse hang.
- Do not seal your walls.
- Do not trim from the front or get paste on the front.
- Do not crease wallcovering.
- Do not pull panels once they have been placed on the wall: this will cause the seams to open after the product dries (Treat the product like a silk wallcovering).
- Avoid direct or bright sunlight. Not guaranteed against fading or color change.

05/01/11

CONTINUED 



MAYA ROMANOFF

Chicago Headquarters: 3435 Madison, Skokie, IL 60076 t 1.773.465.6909 f 1.773.465.7089 www.mayaromanoff.com

STOP!

**Do not install until you have read these instructions
Call 800.465.6909 with any questions**

HANDLING AND INSTALLATION INSTRUCTIONS

Custom Beadazzled™ Flexible Glass Bead Wallcovering Murals (MR-BD series)

This is not a seamless product. Lighting will affect appearance of final installation.

WALL PREPARATION

- Paint the wall the color of the product with a good quality, non-sealing flat latex wallpaint. Avoid super sealing wall prep products. They can cause product to bubble.
- Walls must have a Level 5 finish.
- Do not install on sealed walls without hanging lining paper.
- Walls must be completely dry before installation can begin.
- Apply a coat of Maya Romanoff's MR-RA-838-1 or MR-RA-838-5 or a good quality HEAVY-DUTY, PRE-MIXED, NON-STRIPPABLE, CLEAR, VINYL, LOW WATER CONTENT adhesive* to the wall.

CEILINGS

- Ceiling installations require a two-person team.
- For ceiling installation, prep ceiling with Maya Romanoff's MR-RA-555-1 or MR-RA-555-5 or a good quality VINYL OVER VINYL NON-STRIPPABLE adhesive.* ALLOW TO TACK UP.
- Apply VINYL ON VINYL adhesive to the product. Use a 3/8" nap roller to apply adhesive to avoid getting any paste on seam lines. (Getting paste on seams may cause yellowing.) Allow to rest 5-8 minutes.
- **DO NOT GET PASTE ON FACE OR EDGES OF PRODUCT, SIMILAR TO A SILK TEXTILE INSTALLATION.**

TRIMMING

- Trim with a very sharp, single edge razor blade. USE A NEW BLADE FOR EACH CUT.
- Exposed edges should be installed using the factory edge. Create a template for tight corners or any surface that is not square. When you cannot make a template, warming with a hair dryer will allow easier trimming (from face only).
- Color edges of panel to match image used.
- This product cannot be double-cut on the wall; trim the material from the back side on a table only when necessary.

ADHESIVE

- Use Maya Romanoff's MR-RA-838-1 or MR-RA-838-5 or a good quality HEAVY-DUTY, PRE-MIXED, NON-STRIPPABLE, CLEAR, VINYL, LOW WATER CONTENT adhesive.* Apply a generous, even coat of adhesive to the product being careful at the edges so that adhesive does not get on any overhanging beads.
- Allow to rest 5-8 minutes.
- To avoid getting paste on face of product, use a 3/8" nap roller to apply adhesive.
- You can protect the face of the installed drops from adhesive using 3M Blue Tape.

*For more information on Maya Romanoff's MR-RA-838-1, MR-RA-838-5 or MR-RA-555-1, MR-RA-555-5, check out www.mayaromanoff.com.

05/01/11

CONTINUED 



MAYA ROMANOFF®

Chicago Headquarters: 3435 Madison, Skokie, IL 60076 t 1.773.465.6909 f 1.773.465.7089 www.mayaromanoff.com

STOP!

**Do not install until you have read these instructions
Call 800.465.6909 with any questions**

HANDLING AND INSTALLATION INSTRUCTIONS

**Custom Beadazzled™ Flexible Glass Bead Wallcovering Murals
(MR-BD series)**

This is not a seamless product. Lighting will affect appearance of final installation.

HANGING

- Adhere product to the wall using a bristled nylon brush.
- Smooth product to the wall using a plastic smoother. Smooth continuously to remove any bubbles.
- Use a wooden seam roller to set the seams.
- Use a corner roller to ease the material into moldings, casework, etc., prior to trimming.
- Once product is adhered to wall, warming with a hair dryer (do not use a heat gun) on seams will allow you to push seams tightly together. USE CARE!

CLEANING

- Blot any excess debris—do not rub.
- Dampen the area using a soft cloth and a very weak solution of a very mild liquid detergent.
- Use canned air to raise any imbedded material to the surface.
- Blot the product dry with a soft cloth.

05/01/11



MAYA ROMANOFF®

Chicago Headquarters: 3435 Madison, Skokie, IL 60076 † 1.773.465.6909 ‡ 1.773.465.7089 www.mayaromanoff.com