

STOP!

**Do not install until you have read these instructions
Call 800.465.6909 with any questions**

HANDLING AND INSTALLATION INSTRUCTIONS

Fabricadazzle™
(MR-FDW series)

PLEASE CHECK PRODUCT BEFORE CUTTING.

QUICK FACTS

- Paste: Maya Romanoff's MR-RA-888-1 or MR-RA-888-5 or a good quality clear, strippable, pre-mixed, vinyl adhesive.
- Do not reverse hang.
- Prepaste the wall.
- Level 5 finish.
- Double-cut.
- Please read the following installation instructions before proceeding.
- **IF YOU DO NOT FOLLOW OUR INSTALLATION INSTRUCTIONS, MAYA ROMANOFF WILL NOT ACCEPT RESPONSIBILITY FOR THE INSTALLATION—YOU WILL BE INSTALLING AT YOUR OWN RISK.**

GENERAL GUIDELINES

- Inspect goods carefully. No returns on cut goods.
- Confirm that you have the correct color and product before installing. Additional yardage from this dye lot may not be available.
- **DO NOT REVERSE HANG.** The patterns have a distinct vertical directionality and cannot be reversed.
- **No allowances will be made after THREE (3) drops—Call 800.465.6909 immediately if you encounter any difficulties.**
- No claims allowed for labor charges or consequential damages under any conditions.
- Wallcoverings can display certain irregularities that are inherent to the manufacturing process.

ACTIONS TO AVOID

- **Paste wall directly. Do not paste the wallcovering.**
- Do not rub face of the product with a stiff brush.
- Do not crease wallcovering.
- Do not pull panels once they have been placed on the wall: this will cause the seams to open after the product dries.
- Do not let paste dry on the face of the product.
- Avoid direct or bright reflected sunlight. Not guaranteed against fading or color change.

05/01/11

CONTINUED



MAYA ROMANOFF

Chicago Headquarters: 3435 Madison, Skokie, IL 60076 † 1.773.465.6909 ‡ 1.773.465.7089 www.mayaromanoff.com

1

STOP!

**Do not install until you have read these instructions
Call 800.465.6909 with any questions**

HANDLING AND INSTALLATION INSTRUCTIONS

**Fabricadazzle™
(MR-FDW series)**

PLEASE CHECK PRODUCT BEFORE CUTTING.

WALL PREPARATION

- Paint the wall the color of the product with a good quality, non-sealing flat latex wallpaint. Avoid super sealing wall prep products. They can cause product to bubble.
- Walls should be mirror-smooth.
- Walls must be very smooth before hanging. Level 5 finish is recommended.
- Do not install on sealed walls with hanging lining paper.

ADHESIVE

- **Paste wall directly. Do not paste the wallcovering!** Allow 2-3 minutes for paste to tack up.
- Use Maya Romanoff's MR-RA-888-1 or MR-RA-888-5 or a good quality CLEAR, STRIPPABLE, PRE-MIXED, VINYL adhesive*.
- Avoid getting paste on face of the wallcovering.
- If any adhesive gets on the face of the product, wipe off immediately with a damp sponge. DO NOT SCRUB.

TRIMMING

- Trim with a very sharp, single edge razor blade. USE A NEW BLADE FOR EACH CUT.
- Best results achieved by double-cutting product on the wall.

HANGING

- Smooth product to the wall using a plastic smoother. Smooth continuously to remove any bubbles.
- Do not smooth face of product with a bristle brush or any other textured smoothing implement.

*For more information on Maya Romanoff's MR-RA-838-1 or MR-RA-838-5, check out www.mayaromanoff.com.

05/01/11



MAYA ROMANOFF®

Chicago Headquarters: 3435 Madison, Skokie, IL 60076 † 1.773.465.6909 † 1.773.465.7089 www.mayaromanoff.com