STOP!
Do not install until you have read these instructions
Call 800.465.6909 with any questions

HANDLING AND INSTALLATION INSTRUCTIONS

Remember Paris™ Wallcovering*

(MR-MR series)

General Guidelines

- Inspect goods carefully. Grade carefully for color flow. Confirm that you have the correct color and product before installing. Additional yardage from this dye-lot may not be available.
- No claims allowed for labor charges or consequential damages under any conditions.
- No allowances for more than three standard (9 ft) drops.
- Wallcoverings can display certain irregularities that are inherent to the manufacturing process.
- Walls should be mirror-smooth. Lining paper should be used if walls have imperfections.
- NO SIDE MATCH.

Actions to Avoid

DO NOT:

- Do not rub face of the product with a stiff brush.
- Do not pull panels once they have been placed on the wall: this will cause the seams to open after the product dries.
- Do not use a seam roller to set the seams. Instead, use a plastic sweep.
- Avoid soaking the paper in water or getting the wallcovering excessively wet. This can cause shrinkage and opening of seams as the wallcovering dries.
- Avoid direct or bright reflected sunlight. Not guaranteed against fading or color change.
- Do not crease wallcovering.

1/08/07

CONTINUED →

*** Formerly Moulin Rouge**

MAYA ROMANOFF®

p 773.465.6909 f 773.465.7089 www.mayaromanoff.com

STOP!
Do not install until you have read these instructions
Call 800.465.6909 with any questions

HANDLING AND INSTALLATION INSTRUCTIONS

Remember Paris™ Wallcovering*

(MR-MR series)

Installation Instructions

PRIMER
- Walls should be painted with a good quality flat Latex wallpaint. Paint should match the color of the wallcovering.

ADHESIVE
- Use a good quality CLEAR, STRIPPABLE, PRE-MIXED VINYL ADHESIVE.
- Apply evenly and adequately. Along the edges, apply paste thicker to avoid seams opening.
- If any adhesive gets on the face of the product, wipe off immediately with a damp sponge. Don't scrub.

TRIMMING
- Trim edges with a very sharp razor blade. (For darker colors, retouch the trimmed edges with a marker the color of the product.)

RELAXING TIME
- Usual Relaxing Time: 4 to 10 minutes
- Do a small test strip to determine the proper relaxing time.

TOOLS
- Adhere product to the wall using a Soft Bristled Nylon Brush.
- Gently smooth product to the wall using a Plastic Smoother.

1/08/07

CONTINUED →

*** Formerly Moulin Rouge**

MAYA ROMANOFF®

p 773.465.6909 f 773.465.7089 www.mayaromanoff.com